救命索発射器　取扱説明書 KM5E

INSTRUCTION FOR LINE-THROWING APPLIANCE

片手で発射装置のグリップをしっかり握り、その上面を水平に保ち（標準射角20度）目標に向ける。

Grasp grip firmly, keep it's upper surface holizontally so that the launcher is directed to an angle of 20°.

5. 発　　射：FIRING!!

引きかんのつけ根を握り締めるように押すと0.5秒後に発射される。

（注）発射する際、ワイヤロープと救命索の先端は、右図のようにねじれ及びもつれがないように配置する。

Squeeze the ring holder with base of thumb. Then rocket is ignited and fired with delay of 0.5 seconds.

(NOTE; Wire and line should be placed without twist or tangle as it is in the right picture)

●保管上の注意事項

使用後は、直ちに発射ケース内部をよく水洗し、（発火装置を外し）拭き取り自然乾燥した後、新しい救命索を挿入（この際、索箱のラベルが発射ケースの上側になるようにする）し、発火装置はゴムキャップをして、発射ケースに取り付け、内ふたとゴムカバーをして、直射日光を避け、乾燥した冷涼な場所に備え付けて下さい。

It should be stowed in cool, dry and approved place, avoiding sunbeams in ship.

★警　　告

1. 人のいる方向に絶対向けないこと。
2. 充電確認を必ず行うこと。
3. 発射角度は、向い風なら標準角度をこれより上げ、追い風なら標準角度を下げること。
4. 点火後、発射まで0.5秒の遅れがある。
5. 期限が切れた発射体、発火装置は、製造業者に廃棄を依頼すること。
6. 発火装置の交換は、発火装置を左に回転させて取り外し、付属のパッキンを発火装置のネジ部端面に適宜貼り付けて固定し、充電確認メーターが上側になるように調整すること。

★WARNING

1. Do not direct launcher to a person nearby.
2. Check the battery is charged.
3. Standard elevation is 20°, the elevation should be adjusted accoring to direction and velocity of wind.
4. The rocket will be launched with a delay of 0.5 seconds from ignition.
5. Time-Expired rockets and igniter should be returned to the maker.
6. Replacent of igniter; Rotate conterclockwise and replace new one so the meter comes upward adjusting by using adhesive tape.

興亜化工株式会社　KOA KAKO CO.,LTD.